DYNAPRO®

# U110
## Wireless Transceiver




User's Manual

## Receiver Function Description




1. 6.35mm audio plug
2. LED display: After turning on the screen blinking search frequency, stop blinking frequency success
3. Power switch: Long press on/off
4. DC SV charging interface

## Transmitter Function Description




1. Connector
2. Frequency indication: flashing on frequency, flashing stop is completed on frequency
3. Power button: Long press on/off
4. DC SV charging interface

## Dimensions




DYNAPRO®

# U110
## گیرنده فرستنده بیسیم




راهنمای فارسی

## توضیحات عملکرد گیرنده




۱- فیش صوتی ۶,۳۵ میلی‌متری
۲- نمایشگر LED: پس از روشن کردن، نمایشگر برای جستجوی فرکانس چشمک می‌زند و پس از یافتن موفق فرکانس، چشمک زدن متوقف می‌شود.
۳- کلید روشن/خاموش: با نگه‌داشتن طولانی، دستگاه روشن یا خاموش می‌شود.
۴- درگاه شارژ 5 DC ولت.

## فرستنده توضیحات عملکرد




۱- اتصال‌دهنده (کانکتور)
۲- نشانگر فرکانس: هنگام یافتن فرکانس چشمک می‌زند و با تثبیت فرکانس از چشمک زدن متوقف می‌شود.
۳- کلید روشن/خاموش: با نگه‌داشتن طولانی دستگاه روشن یا خاموش میشود.
۴- درگاه شارژ 5 DC ولت

## ابعاد و متعلقات

